

UNIPHONE 1140™ QUICK GUIDE


This guide contains basic instructions for using your Uniphone 1140. For more complete instructions, see the user's manual.

Setting up your Uniphone 1140


All you do to set up the Uniphone 1140 is plug it in! You can also install a battery if you want to use the Uniphone 1140 during a power outage.

Be sure to use only the power adapter that comes with the Uniphone 1140.

Installing a battery



Plugging in power and the telephone line



CAUTION! Plug the Uniphone 1140 into a standard household telephone (analog) line only. Any other line type may damage your telephone or Uniphone 1140 and void your warranty.

CALLING

There are two ways to call someone with the Uniphone 1140. You can call by voice telephone or by text telephone (TTY).



Making a voice telephone call


- 1. Pick up the Uniphone 1140 handset.
- 2. Dial the telephone number using the number keys on the Uniphone 1140 keyboard.
- 3. When someone answers, go ahead with your conversation.
- 4. When you are finished with your conversation, hang up the handset.

Answering a voice telephone call

- 1. The Uniphone 1140 rings and the flasher blinks when someone calls.
- 2. Pick up the Uniphone 1140 handset.
- 3. Go ahead with your conversation.
- 4. When you are finished with your conversation, hang up the handset.


Making a TTY call

1. Press the Dial key.



(Pressing the Dial key turns on the TTY. You do not need to press the TTY On/Off key).

2. Type the telephone number using the number keys on the keyboard.



3. Watch the display and signal light for a ring signal.



When you see an answer on the display, type a greeting.



4. When your call is finished, hold down either Shift key and press the TTY On/Off key to hang up.



Answering a TTY call

1. The flasher blinks when the Uniphone 1140 rings.



2. Turn on the Uniphone 1140 by pressing the TTY On/Off key.



3. Type a greeting.



4. When you are finished with your conversation, hold down either Shift key and press the TTY On/Off key to hang up.





Using Voice Carry Over (VCO)

VCO is a technology developed by Ultratec that combines voice and text communications over the telephone. It allows individuals who cannot hear well, but wish to use their own voice, to speak directly to the other person on the telephone and read the other person's response on the text display. The other person's responses are typed for you to read, either by the person himself or by a special operator through a Telecommunication Relay Service (TRS).

This person is calling his doctor's office by using VCO through his relay service.

After calling the relay service and requesting VCO, he speaks directly to the nurse.

When the nurse replies to his question, the CA types the nurse's response, which he can read on his Uniphone 1140 display.



Making a VCO call using a relay service

- 1. Press the $\boxed{\mbox{Dial}}$ key and type the relay number using the number keys.
- 2. When the relay CA answers, press the Menu+V keys to send a VCO request automatically. You will see VCO PLEASE GA on the display.
- 3. After the CA notifies you when VCO is ready, pick up the handset and tell the CA the number and person you want to call.
- 4. The CA dials the number. Watch the display and wait until the CA tells you the call is connected.
- 5. Begin speaking to the person you are calling. You may hold the handset for the entire VCO call. You do not need to put the handset down each time you finish speaking.
- 6. When the other person answers, read his or her response on the Uniphone 1140 display. (The CA types the response.)
- 7. When you see GA at the end of a line, begin speaking again. Continue speaking and reading until the conversation is finished.
- 8. When you are finished, replace the handset and hang up the Uniphone 1140 by pressing the Shift key and the TTY On/Off key at the same time.